

*Ultrasonics Equipped  
Crimp Tool-  
A New Technology for Aircraft Wiring Safety*

William T. Yost (William.T.Yost@nasa.gov)  
Daniel F. Perey (Daniel.F.Perey@nasa.gov)  
Elliott Cramer (K.E.Cramer@nasa.gov)

*Nondestructive Evaluation Sciences Branch  
NASA-Langley Research Center  
Hampton, VA 23681-2199*



# ***Introduction***

## *Overview of Crimp Quality and Possible improvements with this technology*



- Crimp Failures occur for many reasons.
  - At installation
    - Wrong connector, wire size or tool used
    - Improper technique
    - Crimp tool failure (worn jaws), etc.
  - During service life
    - Corrosion effects
    - Wire under stress
- Crimp installation are clearly indicated with the Ultrasonics Equipped Crimp Tool (*patent applied for*).
- Recertification of existing crimps (during service life) is possible

## *Present Practices*




- Procedures
  - Detailed crimping procedures, with QA verification on procedures, are used to ensure good initial crimp quality
- Certification / Calibration
  - Destructive pull-testing of similarly crimped connectors is used to certify tools and procedures
  - *There is no direct verification of a good crimp*
- Verification
  - *No crimp recertification is possible*



## ***The Concept***





# *Basic Concept of Ultrasonic Equipped Crimp Tool*



Operational Signals

## *Basic Concept – A Good Crimp!*



### Ultrasonic Features Of a Good Crimp:

1. Multiple signal paths thru crimp
2. Higher amplitude on time record
3. Low spectral variation in Fourier Transform










## ***Test of Concept***


# *Test of Concept Arrangement*




Simple Electronics that can easily be miniaturized to produce a self contained ultrasonics equipped crimp tool



# *Test of Concept Instrumented Crimp Tool*





## ***Test of Concept Results***

- *Based on using 10 Mhz transducers*
- *16-20 gauge wires used for connections*




# ***Test of Concept: Typical Oscilloscope Waveforms of Good Crimp***


Transducers - 10 Mhz  
Pitch - Catch Mode

Transmitter  
Pulse

First Received Pulse  
Thru Crimp



Received Signal Waveform



Fast Fourier Transform

## **Destructive Pull-Test Confirmation**

Wire gage - 20 AWG.  
Minimum load to pass - 19  
Lbs. Actual load reached -  
34 Lbs. Type of failure -  
wire breakage (*not crimp  
failure*).




## *Test of Concept: Typical Oscilloscope Waveforms of Bad Crimp*


Transducers - 10 Mhz  
Pitch - Catch Mode

Transmitter  
Pulse

First Received  
Pulse Thru Crimp




Received Signal Waveform



Fast Fourier Transform

## Destructive Pull-Test Confirmation

Wire gage - 20 AWG.  
Minimum load to pass - 19  
Lbs. Actual load reached -  
10.4 Lbs. Type of failure -  
wire pullout (*crimp failure*).



## ***Data: Experimental Results***



- *Based on using 7.5 Mhz transducers*
- *16-20 gauge wires used for connections*



# Experimental Setup: Crimp-tool and Tester




- The “Jaw”
- *This study uses incomplete jaw closure to make the “bad” crimps*
- Handle closure is performed in 5 mm increments through standard jaw closure
- Wires and connectors are crimped together
- Crimp tester (Alphatron MPT200A) is used to measure force needed to pull wire-connector crimp apart







# Experimental Set-up: Electronics and Ultrasonics





# Experimental Results: Path Analysis

Transducers - 7.5 Mhz

Pitch - Catch Mode


16 Gauge wire and connectors

## Path Analysis within jaws

- *multiple reflections*
- *Path length measures 35 mm (34.7mm from ultrasonics)*

## Path Length Analysis within connector

- *~ 7 to 8 distinct paths*
- *Length variation among paths ultrasonically measures 0.7mm (16 ga)*




# ***Data from 16 Gauge Wire-Connector Crimp Measurements***



Wire Gauge/ Compression Level	Pulse Height (arb units)	Pulse Width (arb units)	Failure Mode	Pull at Failure (lbs) (Spec=50)
16/1	3.9	2	Pull-out	17.5
16/2	7	2.5	Pull-out	50.2
16/3	31	8	Break (at crimp)	65.1
16/4	73	5	Break (at crimp)	62.0
16/5 (full crimp)	100	6.7	Break (at crimp)	59.7

# ***A Plot of Pull at Failure vs. Ultrasonic Pulse-Height through Crimp-Connector Junction (16 Gauge)***




# ***Data from 18 Gauge Wire-Connector Crimp Measurements***




Wire Gauge/ Compression Level	Pulse Height (arb units)	Pulse Width (arb units)	Failure Mode	Pull at Failure (lbs) (Spec=38)
18/1	4	1.7	Pull-out	7.8
18/2	7	2	Pull-out	24
18/3	12	5.5	Break (at crimp)	42.4
18/4	37	5.5	Break (at crimp)	43.5
18/5 (full crimp)	96	7	Break (at crimp)	43.7



## ***A Plot of Pull at Failure vs. Ultrasonic Pulse-Height through Crimp-Connector Junction (18 Gauge)***





# ***Data from 20 Gauge Wire-Connector Crimp Measurements***



Wire Gauge/ Compression Level	Pulse Height (arb units)	Pulse Width (arb units)	Failure Mode	Pull at Failure (lbs) (Spec=19)
20/1	3	2.5	Pull-out	1.1
20/2	8.9	2.5	Pull-out	11.5
20/3	12.1	2	Pull-out	27.7
20/4	42	7	Break (at crimp)	33.9
20/5 (full crimp)	82	5	Partial Break	33.8

# ***A Plot of Pull at Failure vs. Ultrasonic Pulse-Height through Crimp-Connector Junction (20 Gauge)***





## ***Results and Conclusions from Data***




- Data was presented that examines the use of ultrasonics to evaluate crimp quality for incomplete crimps.
- Ultrasonic interrogation of crimp predicts crimp quality
  - Ultrasonic Pulse Height correlates very well with pull-test results for 16, 18, and 20 AWG wire-crimp connections
  - Ultrasonic pulse width is also a possible predictor for pull-test results
- Ultrasonic Pulse Height indicating a quality crimp is relatively independent of wire gauge




# ***Concept for a Possible Commercial Instrument***

# *Artist Conception of Two Versions of a Commercial Instrument*



Good  
Crimp

Bad  
Crimp




Self-contained Instrument

Simple Pass/Fail Indications

Waveform Analysis Embedded in  
Instrument

Optional Data  
Collection and  
Archival



## *Summary and Future Directions*



- No current instrument for crimp quality assessment
- Ultrasonic instrument can be used to assess and/or verify crimp mechanical integrity and hence crimp quality
- Technique allows for re-inspection / recertification
- A fully developed system will permit improved data and record keeping on critical crimp connections.
- Additional measurements are underway to substantiate these and investigate frequency-dependency of ultrasonic signals used to evaluate crimp quality.
- Investigate wide range of crimp failure modes